

MODEL 4102A


MODEL 4102A Soft Case Model MODEL 4102A-H Hard Case Model



Specifications

	Model 4102A/4102A-H
Measurement Ranges	Earth Resistance:0-12 Ω /0-120 Ω /0-1200 Ω Earth Voltage(50,60Hz):0-30V AC
Accuracy	Earth Resistance: ±3% of full scale Earth Voltage: ±3% of full scale
Overload Protection	Earth Resistance:276V AC for 10 seconds across 2 of the 3 terminals Earth Voltage:276V AC for 1 minute
Safety Standard	IEC61010-1 CAT. Ⅲ 300V Pollution Degree 2, IEC61557
Applicable Standards	IEC60529 IP54
Withstand Voltage	3700V AC for 1 minute
Power Source	R6P(AA)(1.5V)×6
Dimensions	105(L)×158(W)×70(D)mm
Weight	600g approx.
Accessories	7095(Test Leads)×1set(red-20m, yellow-10m, green-5m) 8032(Auxiliary earth spikes)×1set 7127(Simplified measurement probe)×1set R6P(AA)×6, Neck strap, Instruction Manual
	Carrying Case
	Soft Case (4012A) Hard Case (4012A-H)

Accessories



Features


- The latest circuit design permits the instrument to operate with the minimum of influence from earth voltage and earth resistance of auxiliary earth spikes.
- Low power consumption. Only 12V/100mA max.
- Earth resistance value can be read directly from the scale.
- Simplified measurement can be easily made by pressing the "Simplified Meas." switch button only. No need to use a shorting wire as terminals P and C can be internally shorted by pressing this
- Battery replacement can be easily made without removing the carrying case.
- Lead wire connection to C and P terminals and proper auxiliary earth resistance can be checked by "OK" lamp. Lead wire connection to C and E terminals is good when "OK" lamp is illuminated.



MODEL 4102A-H Hard Case Model

Earth Resistance Measurement

Press a desired range switch button first and then "MEAS." button.



Simplified Measurement Method Using **Earthed Side of Commercial Power Supply**

Press a desired range switch button first and then "SIMPLIFIED MEAS." button.

