



Allgemeines

Sie benötigen Ihre Messwerte auf dem PC, wollen diese aber nicht mühsam und fehlerträchtig manuell über die Tastatur eingeben?

EasyExport nimmt Ihnen die Eingabearbeit ab. Über die Schnittstelle des PC werden die Messwerte der KARL DEUTSCH - Geräte eingelesen und nach Ihren Vorgaben in das jeweils aktuelle Programm (Textverarbeitung, Tabellenkalkulation, Datenbank, Warenwirtschaft- und QS-Software u.v.m.) geschrieben.

PC-Voraussetzungen

Betriebssysteme: Windows XP oder 2000
Schnittstelle: Seriell (COM) oder USB
CD-Laufwerk (andere Medien auf Anfrage)
3,0 MB freier Festplattenspeicher

Verwendbare Messgeräte

Die Messgeräte ECHOMETER 1075, LEPTOSKOP 2018/2021/2026/2042 sind standardmäßig für den Betrieb mit EasyExport ausgelegt und werden automatisch erkannt.

Die Geräte ECHOMETER 1074, LEPTOSKOP 2041, DEUTROMETER 3872, RMG 4015 arbeiten mit EasyExport zusammen. Die Geräteauswahl erfolgt manuell.

Bestellnummern


Software EasyExport auf CD
mit Bedienhinweisen: **2905.001**
Kabel zum Anschluss des
Messgeräts an die
Schnittstelle eines PC: **geräteabhängig**

Programmeigenschaften

Bedienoberfläche

Vollständig grafikorientiert im Windows®-Standard (Pushbuttons, Drop-Down-Listen etc). Sprachauswahl: Deutsch, Englisch. Nach der Konfiguration wird EasyExport minimiert und arbeitet im Hintergrund. Ein Symbol im System Tray des Betriebssystems zeigt den jeweiligen Betriebszustand an.

Konfiguration



Konfigurationsmenü (links) und Programmsymbol im System Tray des Betriebssystems (Pfeil)

Im Bereich **Steuerung** legen Sie die Taste oder die Tastenfolge fest, die vom PC automatisch nach der Übernahme eines Messwerts "gedrückt" werden soll. Dadurch werden wie bei der normalen Tasteneingabe Spalten oder Reihen erzeugt oder Felder des empfangenden Programms gefüllt. Über das **Format** wählen Sie, ob der Messwert mit Einheit eingetragen wird und welches Dezimaltrennzeichen gewünscht ist.

Beispiel: Tabellenkalkulation

	A7	
1	96.6 µm	
2	98.7 µm	
3	96.9 µm	
4	98.5 µm	
5	94.2 µm	
6	90.8 µm	
7		
8		
9		

Relevante Einstellungen:

Abschlusszeichen: ENTER
Maßeinheit 2.7 µm/mil/Tesla
Dezimaltrennzeichen: .

Beispiel: Tabelle in einer Textverarbeitung

1	93.6 µm
2	97.2 µm
3	91.5 µm
4	95.1 µm
5	102 µm
6	103 µm
7	
8	
9	
10	

Relevante Einstellungen:

Abschlusszeichen: Runter
Maßeinheit 2.7 µm/mil/Tesla
Dezimaltrennzeichen: .

Als **Schnittstelle** stehen alle freien Schnittstellen des PC zur Verfügung. Falls das Gerät mit einer automatischen Erkennung ausgerüstet ist (siehe links, "Verwendbare Messgeräte"), wird im Bereich **Gerät** die Typenbezeichnung des angeschlossenen Geräts angezeigt. Im Bereich **Messwert** sehen Sie jeden aktuell über die Schnittstelle ankommenden Messwert.

Eingestellte Parameter werden automatisch bei Verlassen des Programms gespeichert und beim nächsten Programmstart wieder verwendet.



Summary

Do you need your measured values on the PC without possibly buggy manual input via the keyboard?

EasyExport takes the input job from you. The interface of the PC is used to read the values of the KARL DEUTSCH instruments to be written to the currently active program (word processor, spread sheet, ERP and QA software and many more) according to your specifications.

PC Requirements

Operating Systems: Windows XP or 2000
Interface: Serial (COM) or USB
CD drive (other media on request)
3.0 MB approx. free HD memory

Suitable Instruments

By default, the gauges ECHOMETER 1075, LEPTOSKOP 2018/2021/2026/2042 can be used with EasyExport since they become detected automatically.

The gauges ECHOMETER 1074, LEPTOSKOP 2041, DEUTROMETER 3872, RMG 4015 can be used with EasyExport as well. Identification, however, is manual.

Order Numbers


Software EasyExport on CD
with operating notes: **2905.001**
Cable to connect a
measuring instrument to
the interface of a PC: **depending on instrument**

Program Specifications

User Interface

Complete graphical design according to Windows® standards (push buttons, drop-down lists, etc). Language selection: German, English. After configuration EasyExport is minimised to the system tray of the operating system. Different symbols then show the current operating state.

Configuration



Configuration menu (left) and symbol in the system tray of the operating system (arrow)

The box area **Control** is used to select the key or the key sequence which the PC automatically will "press" after transfer of the measured value. As with normal input via keyboard this will create columns or rows or input to fields of the receiving program. The inputs in the **Format** box determine whether the reading is entered together with a measuring unit and what decimal separator is to be used.

Example: Spread sheet

	A7	
	A	E
1	96.6 µm	
2	98.7 µm	
3	96.9 µm	
4	98.5 µm	
5	94.2 µm	
6	90.8 µm	
7		
8		
9		

Relevant selections:

Control Character: ENTER
Unit: 2.7 µm/ml/Tesla
Decimal separator: .

Example: Table in a word processor

1	93.6 µm
2	97.2 µm
3	91.5 µm
4	95.1 µm
5	102 µm
6	103 µm
7	
8	
9	
10	

Relevant selections:

Control Character: DOWN
Unit: 2.7 µm/ml/Tesla
Decimal separator: .

All free interfaces of the PC are available when selecting the **Port**. If the instrument is fitted with automatic detection (see left, "Suitable Instruments") the box area **Device** shows the type designation of the currently connected gauge. The box **Measured Value** shows the current reading transferred via the interface.

Once the parameters are selected they will be memorised for next start-up of the program.